

How to Use the Auditorium (IAC) AV Switcher



This guide explains how to connect laptops and the AV room desktop to the Auditorium AV system using the **IAC AV switcher**.

“ Important:

- The **top row** of buttons contains **outputs**.
- The **bottom row** of buttons contains **inputs**.
- **Do not touch any equipment below the AV switcher** unless you have consulted IT first.

Connecting a Laptop ?

Laptop HDMI ports are available around the Auditorium:

- One on either side of the stage
- Atop the stairs below the AV room window
- Inside the AV room

Steps:

1. On the **input row (bottom row)** of the AV switcher:
 - Select your **HDMI port number** on the left side while **Video** is selected on the right side.
 - Select the same **HDMI port number** on the left side while **D-Audio** is selected on the right side.

Tip: Make sure your laptop is powered on and connected to the correct HDMI port before selecting inputs.

Connecting the AV Room Desktop ??

If using the **desktop computer in the AV room**, on the **input row (bottom)**:

- Select **Number 1** on the left side while **Video** is selected on the right side.
- Select **Number 1** on the left side while **D-Audio** is selected on the right side.

Sending Output to the Projector ??

1. On the **output row (top)** of the AV switcher:
 - Select **Number 1** on the left side while **Video** is selected on the right side.
 - Select **Number 1** on the left side while **D-Audio** is selected on the right side.
2. Ensure the **projector is powered on** using the remote.

“ **Note:** There should be no need to press any other buttons on the projector remote. All AV functionality is controlled via the AV switcher.

Mirroring Your Laptop to the Desktop ? ? ??

1. On the **output row (top)** of the AV switcher:
 - Select **Number 2** on the left side while **Video** is selected on the right side.

“ This allows your laptop screen to display on the AV room desktop.

Reminder: If you encounter any issues, contact the IT department before adjusting any equipment below the AV switcher.

Revision #3

Created 2024-08-29 04:02:42 UTC by Administrator

Updated 2025-09-10 03:55:29 UTC by 10020431